

Lamp Replacement RELAX GLASS MULTI, 3000 watts (additional to replacement manual 1500/1800/2200W)

1. Please check if **A**, **B** and **C** are loose or not.
2. If they are good, please check the value at the point of **A - C** at the same time by the digital multimeter.

A: If there are numbers that can be read, the mean that both of two lamps are ok.
As per our data, the lamp resistant should be 3.3 ohm in the cool condition.

B: If the value is 0, please check it at the point of **A - B** and **B - C** to find out the bad lamp.
3. Please follow the procedures No. 5 to 12 in the 1500/1800/2200W replacement instructions. And check the value at the point of **A - C** by digital multimeter again until there are numbers that can be read. Then follow No. 13 to 16 of the lamp replacement manual.

