




## PC ECO PUMP OIL



I have attached a labeled photo to help explain how to measure the oil and where to fill. Also, when looking into the oil window the level should be within the two yellow lines. Sometimes it helps to shine a flashlight into the top so the oil level can be seen more clearly in the window.

The engine oil ending in either W30 or W40 is fine. Whichever oil in this range people there are already using will be acceptable. The exact grade of the oil is far less important than having a regular maintenance routine and changing it periodically. The first change should be after the first 50 hours of use. Thereafter the oil should be changed every 100 to 200 hours of use. But the most critical point is to not run the pump without oil. I really can't stress that enough.