


SMART 4000

1. Remove the lamp

Step 1




Step 4



Step 2




Step 5



Step 3



Step 6




SMART 6000


Step 7




Step 10




Step 8




Step 11



Step 9




Step 12




SMART 6000


Step 13




Step 16




Step 14




Step 17



Step 15




Step 18



SMART 6000


Step 19




Step 22




Step 20




Step 23



Step 21




Step 24




SMART 6000


Step 25



Step 26



Step 27



SMART 6000

